



**APTUM**  
CUSTOMIZED  
LIGHTING  
CREATIONS

## **GLOW**

user instructions

Congratulations on choosing this original "GLOW" light designed by APTUM. We hope you will enjoy using this product. Please follow these instructions to ensure correct installation. If you have any questions or comments, please do not hesitate to contact us by mail on:

[info@aptumlighting.com](mailto:info@aptumlighting.com)



Please read these instructions carefully and retain them for future reference to ensure that the lamp is used correctly.

For your own safety, please study each step of this instruction manual first. APTUM is not responsible for any faults or damages caused by not following these instructions correctly. Do not modify this lamp in any way.



# GLOW

## **SAFETY PRECAUTIONS**

- Dispose of plastic bag from packaging and do not allow children to play with it.
- Keep product well out of children's reach.
- The lamp is only intended for interior use.
- Do not attempt installation of product if you are not competent to do so yourself.
- Consult a professionally qualified electrician if in any doubt.
- Disconnect the electricity supply at the fuse box, before commencing work.


## **CLEANING INSTRUCTIONS**

- Switch off the electricity supply before cleaning.
- Wipe surface of the lamp with a soft dry cloth.
- Do not use any abrasive cleaning tools such as steel wool, scouring sponges or stiff brushes.



## GLOW

Content of box




### WHAT DO YOU NEED?

- 2 Persons to install
- Drill diameter 8mm
- Philips head screw driver
- Cut pliers




## INSTALLATION MANUAL



### STEP 1

Turn out the inner part of the ceiling attachment.




### STEP 2

Make sure the ceiling is strong enough to hold the Glow lamp (3,5 kg). The plug provided is suitable for most materials (e.g. concrete/plaster). If necessary, use a suitable alternative plug.

Mark the location where to install the ceiling attachment. Make sure that the centerline is at 80 mm or more from the center of the electricity point.

Drill a 8 mm hole in the ceiling and put in a plug. Secure the ceiling attachment with the screw and tighten it.




### STEP 3

**! HOLD THE GLASS GLOBE FIRMLY!**

Get the steel cable.

Insert the steel cable into the inner part of the ceiling attachment.

Now you can insert the steel cable into the small hole at the outer part of the ceiling attachment. Make sure the steel cable comes out at the side hole of the ceiling attachment.




### STEP 4

Turn in on the inner part of the ceiling attachment.


If you want to lower the lamp, push in the small tube at the bottom, the steel cable gets loose again.

Thanks to gravity, the glow lamp hangs on your ceiling.




### STEP 5

You can cut the steel cable with a cutting plier to size as desired.




### STEP 6


Take the electricity cable and put the plastic cap over the end of the wire.



### STEP 7



Fix the electric cable around the hook of the electra point.






### STEP 8

Connect the electric cable to the terminal block.




### STEP 9

Place the hook with the electric cable over the hook of the electricity point.



### STEP 10

Slide the plastic cap upwards until it touches the ceiling.




### STEP 11

Finally, you can use the clips to attach the electricity cable to the steel cable.  
Step back and admire your work  
Enjoy!




## REPLACING THE LIGHT BULB



### STEP 1


**! HOLD THE GLASS GLOBE FIRMLY!**

Take a flat screwdriver and unscrew the plastic screw from the metal cap.




### STEP 2

Now you can turn out the metal cylinder of the metal cap.




### STEP 3

Lift up the metal cap of the lamp.




### STEP 4

Hold the glass globe firmly and slide it over the metal interior of the lamp.




### STEP 5

Put the glass globe safely aside.  
Now you can replace of the old LED bulb with a new one.




### STEP 6

Place the glass globe over the metal interior again. Make sure the edges of the glass globe are placed in the cutouts of the metal interior. This way the glass globe can no longer move.




### STEP 7

Lower the metal cap back over the glass globe.



### STEP 8

Turn back on the metal cylinder on the metal cap.



### STEP 9

Turn the plastic screw back into the metal cylinder. Don't over-tighten or the plastic screw will break.

CE □ ▽ F IP20 



**APTUM**  
CUSTOMIZED  
LIGHTING  
CREATIONS

**CONTACT**

Phone: +31 40 220 4500

Email: [info@aptumlighting.com](mailto:info@aptumlighting.com)

**ADDRESS**

Gashouder 13

5613 CR Eindhoven

The Netherlands

**WEBSITE**

[www.aptumlighting.com](http://www.aptumlighting.com)

